



INSTALLATION INSTRUCTIONS COATINGS

SURFACE PREPARATION

Before applying a ConSeal primer or coating, ensure the concrete is devoid of dust, dirt, oils, grease, form release agents, curing compounds, laitance, and debris. Do not apply ConSeal primers or coatings over an existing coating without contacting ConSeal's technical team. Conduct a thorough inspection of the surface's integrity. Static hairline cracks should be sealed with a cementitious paste or with an epoxy injection in accordance with ASTM C881. Remove sharp edges or concrete splatter. Start the coating application process **ONLY AFTER** the surface is verified to be clean, sound, and sufficiently dry per the primer or coating requirements. If necessary, patch or repair damaged areas, honeycombing, exposed rebar, etc. Testing shall be done in advance to assure compatibility of coating with the patching materials.

Concrete can be prepared using vacuum cleaning, air blasting, and water cleaning as described in ASTM D4258. Detergent water cleaning and steam cleaning as described in ASTM D4258 may be used to remove oils and grease from the concrete surface. To remove loose concrete, laitance, and to expose surface voids, dry adhesive blasting, wet adhesive blasting, vacuum-assisted abrasive blasting, and centrifugal shot blasting as described in ASTM D4259 may be used. High pressure water jetting as described in ASTM D4259 may also be used.

Acid etching as described in ASTM D4260 may be used to remove laitance and weak concrete. All acidic materials shall be removed from the concrete and the pH of the concrete shall be tested to assure the acid has been neutralized. Some sealers or primers may prohibit the use of acid etching. Hydrochloric acid, such as muriatic acid, is not to be used where metal (e.g., rebar) is exposed.

NOTE: When using a coating for the first time, it is advisable to coat a small test patch on a representative section of concrete and verify adhesion before proceeding to large scale coating projects.

TESTING OF A COATING SYSTEM

All concrete has unique variations. Concrete coating systems should be tested on the concrete intended for use along with adhesion performance testing as described in ASTM D7234. For further testing use ACI 302.2 as a guide.

For testing, a simple method that can be used in the field is ASTM D3359, Test Method A. An 'X' is cut into the coating with a sharp knife. Then, 1" (25 mm) wide pressure sensitive tape is placed along the center of the cut that was made, pressed firmly into place, and removed by a quick pull. Check for a loss of coating, especially at the intersection of the 'X'.

PRIMING

ConSeal CS-80 and ConSeal CS-85 are specifically designed for ConSeal's elastomeric coatings (CS-55, CS-1200, and CS-1800). CS-90 and CS-95 epoxy coatings, do not require a surface primer.

DO NOT USE PETROLEUM SOLVENTS SUCH AS MINERAL SPIRITS OR XYLENE FOR SURFACE PREPARATION. DO NOT THIN OR DILUTE ANY CONSEAL PRIMERS OR COATINGS BEFORE USE.

CS-80 SOLVENTBORNE PRIMER - Begin by ensuring the concrete surface is clean, intact, and completely dry. Once this is confirmed, you can immediately start applying a uniform layer of CS-80 primer to the area. Apply the primer evenly across the concrete and wait for it to dry. Inspect the coated surface for any missed spots or voids. **Apply only one coat of primer to the surface. Multiple coats may cause delamination.** After use, immediately secure the primer's lid to prevent it from drying out.

CS-85 WATERBORNE PRIMER - Before beginning the CS-85 application, confirm that the concrete surface meets one of two conditions: it has been air cured and dry for a minimum of 48 hours, or it has a surface moisture reading of less than 5%¹. Once you have ensured the surface is clean, undamaged, and dry, you can apply CS-85 primer. Apply the primer evenly across the concrete and wait for it to dry. **Apply only one coat of primer to the surface. Multiple coats may cause delamination.** Inspect the coated surface for any missed spots or voids. After use, immediately secure the primer's lid to prevent it from drying out.

¹ConSeal uses a Tramex CMExpert II digital concrete moisture meter for instant surface moisture readings.

STORAGE

DO NOT FREEZE! Always keep the containers sealed when they are not being used. Ensure that unopened containers are safeguarded against water, heat, and direct sunlight. It is important to store these original, sealed containers in an environment that is both cool and dry, ideally within a temperature range of 40°F to 90°F. If a spill occurs, contain it using an inert absorbent material, like sand, vermiculite, or kitty litter. Then, dispose of the waste responsibly, following all relevant local, state, and federal environmental regulations. Be aware that storing the product at temperatures above 100°F can decrease its shelf life. Once opened, pails should be used within six months for optimal quality.

CLEAN UP

Mechanical scraping will be necessary for cured product. Water based coatings that are still wet can be removed with warm, soapy water. All other coatings to be cleaned with denatured alcohol, MEK, or Acetone.

LIMITATIONS

- In areas where prolonged chemical exposure is anticipated, contact Concrete Sealants, Inc. for recommendations.
- Do not apply at temperatures below 40°F (4°C).
- Do not use on surfaces with an existing coating unless the coating is completely removed or otherwise advised by Concrete Sealants, Inc. technical staff.

KEEP ALL PRIMERS AND COATINGS OUT OF REACH OF CHILDREN

REFER TO CONCRETE SEALANTS SAFETY DATA SHEETS FOR ADDITIONAL INFORMATION

ENVIRONMENTAL CONDITIONS

The age of the concrete shall be as specified by the coating being used. The moisture content of the concrete shall not exceed the measure specified by the coating being used. The moisture test shall be completed after cleaning and drying, but before the application of the coating¹. Coatings shall be applied when the air temperature is within 20°F of the high temperature of the day. The relative humidity of the coating environment shall not exceed 80% at any time during application or curing for waterborne coating and waterborne primer products. If coating indoors, maintain a temperature range within 20°F during the application and curing of the coating. Additionally, the air temperature and the temperature of the concrete to be coated shall be a minimum of 5°F above the dew point temperature and rising.

ALL COATINGS SHALL NOT BE APPLIED TO FROZEN CONCRETE WITH A CORE TEMPERATURE BELOW 32°F.

APPLICATION INSTRUCTIONS

CS-90 APPLICATION: Stir both Part A and Part B components thoroughly in their separate containers before use, ensure no settling on bottom of Part B container. A primer shall not be used for ConSeal's CS-90 Waterborne Epoxy Coating. However, ensure the surface is devoid of dust, dirt, grease, form release agents, laitance, and debris. Once mixed individually, gradually combine the entirety of Part B into Part A (1:1 mix ratio by weight), stirring continuously until a color is homogeneously seen throughout the container. When applying the coating, use a brush or roller and aim for a recommended thickness of 6-10 mils wet. The ideal application temperature range is between 40°F and 120°F. The curing process typically takes 3 hours, and this duration can decrease with higher environmental temperatures; note that the coating will not cure effectively in temperatures below 40°F. If applying an additional layer, once the applied coating is cured (approx. 3 hours), another coat may be applied, abrade surface for maximum performance. CS-90 can be sprayed with professional, plural component spray equipment. Contact ConSeal for further details.